

Caring for your bath.

The surface is hand-polished and the colour runs right through it. Looked after simply, it will stay as it left us for decades.

EVERYDAY SURFACE CARE

Clean with	A soft cloth and warm soapy water, or a non-abrasive bathroom cleaner.
Avoid	Abrasive pads, scouring creams and solvent cleaners — they dull the polished finish.
Salts	Bath salts and Epsom salts can stain the surface and are not covered — avoid them.
A dull patch?	Light polishing compound restores the sheen, because the colour is all the way through.

THE JET-SYSTEM CLEAN CYCLE

Fill the bath to about 5 cm above the highest jet.

Add the recommended cleaning solution and run the jets for at least five minutes.

Let it stand for one to two hours, then run again briefly and drain.

On power-down the system automatically blow-dries the pipework — so there is no stagnant water and no build-up between uses.